









# Interruttori a pulsante





Push-button - Bouton - Drucktaste





Pulsante avviamento **105.000 N**  
Starting switch  
Bouton demarrer  
Anlasser drucktaste




Pulsante avviamento **105.001 N**  
Starting switch  
Bouton demarrer  
Anlasser drucktaste

Pulsante avviamento **105.002 N**  
Starting switch  
Bouton demarrer  
Anlasser drucktaste

Pulsante avviamento **105.003 N**  
Starting switch  
Bouton demarrer  
Anlasser drucktaste

IDEOGRAM  
Client's logo  
on request

AVAILABLE IN:  
DISPONIBILE IN:

RED  
GREEN  
ORANGE  
YELLOW  
BLACK  
BLUE  
WHITE

Pulsante **105.004**  
Push - button **105.005**  
Bouton **105.006**  
Drucktaste **105.007**  
**105.008**  
**105.009**